

# SURFACE MOUNT PANEL INSTALLATION



## Detectable Warning Systems

### Recommended Surface Mount Panel Instructions:

1. Read and follow all manufacturer instructions on the adhesive container.
2. Installation area should be dry. New poured concrete should be cured for a minimum of 48 hours.
3. Clean the desired area of all debris, oil, grease, dirt, etc.
4. Wipe down back of the detectable warning panel to remove dirt and debris.
5. Cut nozzle tip and insert into a heavy duty or battery operated caulking gun.
6. Apply a uniform bead (approximately 1/4") of "adhesive" to scratched rib areas. Apply another bead of adhesive on all (4) edges to properly seal panel perimeter. Remaining adhesive may be placed on remaining scratched areas.
7. Place the detectable warning panel at the desired location and apply pressure. Adhesive should squeeze out under the perimeter of the panel.
8. Drill holes through the notches and concrete, insert anchor and hammer until ridge is flush to dome.
9. Tape 1/4" around all edges and apply thin bead of adhesive. Protect from foot and vehicular traffic until adhesive has hardened.

The above installation instructions are not meant to override application codes or local agency's requirements.

